

HOW TO FIX, CLEAN AND TAKE CARE OF YOUR simpl. VOLUMES

Even though our products are made of high-quality materials, they need to be handled with care to make sure they will last long. So please consider our recommendations to fix, clean and take care of simpl. volumes:



FIX

- Volumes should only be fixed by certified route setters.
- If a volume has any defect, do not fix it on the wall.
- Fix volumes to a completely flat surface.
- Use min. 4,5 mm screws and make sure there are enough fixing points so it is impossible to pull out a volume in any given situation.
- Do not over-tighten when fixing volumes.



CLEAN

- We recommend cleaning your volumes with high-pressure washer machine. Water temperature should not be higher than 40 °C. Make sure you are washing from minimum distance of 35 cm, otherwise you can potentially damage the products and affect the color.
- Volumes should not be washed with detergents or other aggressive acid-based products. For effective cleaning, we advise you to use a specific washing liquid or jet wash.
- Volumes should not be soaked in water. After a fast cleaning it is important to put them in a dry place immediately.
- Only use a soft brush when cleaning volumes on the wall. Other brushes may damage the surface volumes.



CARE

- Note that longer exposure to sun and therefore UV may change the shade of color of volumes.
- Volumes need to be handled with care. Any falling, dropping, throwing or storing volumes where rubbing against one another is possible may result in visible scratches or other damage on volumes.
- If sharp edges appear due to mishandling volumes, they should be removed using sand paper or other abrasive material.
- Store them in dry place.

Thank you for reading our recommendations, and for handling our volumes with care.

